

REPLACE YOUR BOOTS, PREVENT A BIGGER AND EXPENSIVE REPAIR

BOOTS REPAIR KIT

Water and dirt can make them fail:

Transmission → Protect it with CV JOINT BOOT (D8*)

Steering rack → Protect it with STEERING BOOT (D9*)

Shock absorber → Protect it with SHOCK ABSORBER PROTECTION KIT (D5*)

CHECK AND REPLACE THE BOOTS WITHIN EVERY MAINTENANCE OPERATION

AUTOFREN SEINSA manufactures under the same specifications as OE.
And therefore we have the ISO 9001:2015 and IATF 16949:2016 certifications.

CV BOOT (D8*)



STEERING BOOT (D9*)



SAPK (D5*)



**HOW TO REPAIR A CV BOOT?
SCAN QR CODE**



**HOW TO REPAIR A
STEERING BOOT?
SCAN QR CODE**



**HOW TO REPAIR A SHOCK
ABSORBER PROTECTION KIT?
SCAN QR CODE**